



## 700 Series Pushbuttons

### Overview

Schlage Pushbuttons are used to control the ingress and/or egress of a door. The 700 Series Pushbuttons are easy to install and operate.

Schlage 700 Series Entry Level Pushbuttons are designed to meet commercial applications. Use with egress swinging or sliding doors that are electrically or electronically locked. 700 Series Entry Level Pushbuttons are available for single gang and narrow stile applications. The 709 model, includes backlit buttons with "PUSH TO EXIT" or Handicap Symbol to meet ADA requirements.



System Components  
700 Series Pushbuttons

### Features and Benefits

- Single gang and narrow stile
- Standard stainless steel
- Momentary action (standard)
- Options include LEDs, alternate action – maintained (AA)

<b>700 Specifications</b>	
<b>701 Pushbutton</b>	
<b>Contact Ratings</b>	5 amps @ 250 VAC
<b>Wire Leads</b>	20 awg – 6" long
<b>709 Pushbutton</b>	
<b>Contact Ratings</b>	10 amps @ 250 VAC
<b>Wire Leads</b>	20 awg – 8" long
<b>Input requirements with LED option</b>	
<b>Voltage</b>	12/24 VDC
<b>Current Draw</b>	30 mA
<b>Wire Leads</b>	24 awg – 6" long
<b>Input requirements with ILL option</b>	
<b>Voltage</b>	12 VDC for 709 series only 24 VDC for 701/709 series

#### ORDERING INFORMATION

<b>701RD</b>	7/8" Red Mushroom Button
<b>701BK</b>	7/8" Black Mushroom Button
<b>701RD EX</b>	5/8" Red Button - Engraved "PUSH TO EXIT"
<b>701RD EX ILL</b>	5/8" Red Button – Illuminated "PUSH TO EXIT"
<b>709RD EX ILL</b>	2" Red Square - Illuminated "PUSH TO EXIT"
<b>709GR EX ILL</b>	2" Green Square – Illuminated "PUSH TO EXIT"
<b>709BLH ILL</b>	2" Blue Square – Illuminated Handicapped Symbol

#### OPTIONS

<b>L2</b>	Two LEDs, red and green, dual voltage
<b>AA</b>	Alternate Action – Maintained (not available for 709 models)
<b>NS</b>	Narrow Stile plate (not available for 709 models)

